



USING THE OX


① Plug in lights 

② Turn on Oxberry




③ Hit the "BUCKLE" button. The red light should now be off.

④ Open viewfinder, check to see image.



Everything within the outermost box will appear on film.

⑤ Adjust the zoom/height of the camera by turning the zoom "on", then adjusting up or down.




⑥ Ready to shoot? Make sure everything looks how you want it to, then close the viewfinder. To take a frame, push the "Expose" button. This will take 1 frame. To take 2, hit twice, etc.



- To expose continuously, switch the setting from "S.M." to "CONT."
- To keep track of how many frames you've shot, use the counter.

CONT. S.M.



COUNTER

WHEN YOU'RE DONE:

Turn all switches to "off" and unplug lights.